




SPARE PARTS LIST


BRUSHCUTTERS/CLEARING SAWS

128 R, 952715752, 2010-08



⚠ WARNING
 All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref	Diel č.	Popis	Poznámka	Mno žstvo	SADA
1	574 81 07-01	KUŽEL'	2010-72N AND LOWER, SEE SERVICE REFERENCE	1	
2	574 81 03-01	KUŽEL'	2010-72N AND LOWER, SEE SERVICE REFERENCE	1	
3	530 01 64-49	SKRUTKA	2010-72N AND LOWER, SEE SERVICE REFERENCE	1	
4	530 01 58-05	SKRUTKA	2010-72N AND LOWER, SEE SERVICE REFERENCE	1	
5	537 17 28-02	RUKOVAŤ		1	
6	503 20 02-45	SKRUTKA IHSCFM		1	
7	545 05 66-01	SVORKA		1	
8	530 01 59-40	SKRUTKA		1	
9	545 12 55-01	TIAHLO - ZOSTAVA		1	19-30
10	502 19 95-03	PRETLÁČACIA LOPATKA		1	
11	731 23 14-01	ŠEŠŤUHOLNÍKOVÁ MATICA		1	
12	537 17 29-01	COVER		1	
13	502 21 12-01	SPONA		1	
14	545 11 33-01	SVORKA		1	
15	575 77 60-01	KIT		1	40,41,42 ,45,47
16	530 01 58-14	SKRUTKA		1	
17	530 05 85-63	CLAMP BRACKET,		1	
18	545 05 85-01	DRŽIAK		1	
19	537 41 90-01	VYPÍNAČ		1	
20	537 16 07-03	STARTER THROTTLE LOC		1	
21	537 17 43-01	PRUŽINA		1	
22	503 22 10-13	ŠEŠŤUHOLNÍKOVÁ MATICA		1	
23	506 49 51-01	OVĽÁDACIA POISTNÁ PÁČKA		1	
24	537 16 02-03	HANDLE HALF LEFT		1	
25	545 12 58-01	ASSEMBLY		1	
26	537 17 42-01	SPRING THROTTLE TRIG		1	
27	506 49 50-01	OVĽÁDACIA PÁČKA		1	
28	503 21 66-18	SKRUTKA IHSC		1	
29	503 20 07-35	SKRUTKA IHSCFM		1	
30	537 16 03-01	HANDLE HALF RIGHT		1	
31	545 00 75-07	HRIADEL'		1	
32	537 21 63-01	HARNESS		1	
33	545 03 09-01	COMBI GUARD		1	34, 35, 44
34	530 05 22-86	LINKA		1	
35	530 01 58-14	SKRUTKA		1	
36	504 00 13-03	GRASS BLADE		1	
37	503 89 01-01	PODPORNÁ MISKA		1	
38	537 28 56-01	PODPORNÁ PODLOŽKA		1	
39	503 85 63-01	MATICA		1	
40	530 01 60-14	SKRUTKA		1	
41	545 00 39-02	SKRUTKA		1	
42	575 72 46-01	ZÁSTRČKA		1	
43	537 23 49-01	HNACIE KOLESO - ZOSTAVA		1	
44	530 01 57-71	SKRUTKA		1	
45	530 05 75-54	DRŽIAK		1	
46	502 28 59-01	STOP		1	
47	530 09 62-95	KUŽELOVÝ PREVOD		1	
48	537 33 83-06	ŽACIA HLAVA		1	



MOTOR

128 R, 952715752, 2010-08

Ref	Diel č.	Popis	Poznámka	Mno žstvo	SADA
1	530 15 02-53	VZDUCHOVÝ FILTER		1	
2	530 01 61-01	MATICA		1	
3	530 05 78-44	PÁKA		1	
4	530 05 87-09	PRIMER BULB		1	
5	545 00 80-86	KIT-CARB. GASKET		1	7,65
6	530 03 55-96	ADAPTER		1	
7	545 00 80-84	SADA TESNENÍ		1	
8	530 01 64-00	SKRUTKA		1	
9	952 03 02-01	ZAPALOVARIA SVIEČKA		1	
10	545 00 80-84	SADA TESNENÍ		1	
11	545 00 80-84	SADA TESNENÍ		1	
12	503 87 33-05	STARTER PAWL BRIDGE		1	
13	530 09 56-46	FILTER		1	
14	530 06 95-99	HADICA		1	15
15	530 02 38-77	VÝSTUPOK		1	
16	530 15 03-50	UZÁVER NÁDRŽE		1	17
17	545 00 80-84	SADA TESNENÍ		1	
18	530 05 97-80	IZOLÁTOR		1	
19	545 18 08-70	KIT-FUEL TANK ASSY.		1	13, 14, 15, 16, 17, 18
20	576 38 21-01	KIT		1	
21	530 01 64-48	SKRUTKA		1	
22	545 00 80-79	KIT-ROPE		1	
23	545 04 32-05	RUKOVÄŤ		1	
24	530 01 64-26	SKRUTKA		1	
25	530 01 64-49	SKRUTKA		1	
26	576 38 21-01	KIT		1	
27	545 00 80-87	PRUŽINA		1	
28	545 00 80-78	KIT-STARTER PULLEY		1	
29	544 03 88-02	PRUŽINA		1	
30	544 03 87-02	HNACIE KOLESO		1	
31	530 01 64-68	SKRUTKA		1	
32	576 36 83-01	ASSEMBLY		1	22, 23, 25-31
33	530 05 89-82	SKRUTKA		1	
34	530 01 52-41	SKRUTKA		1	
35	530 15 04-40	PROTECTOR		1	
36	530 01 64-49	SKRUTKA		1	
37	576 21 50-01	KIT		1	
38	545 03 05-01	SITKO		1	34
39	574 03 15-02	KIT		1	33, 34, 38, 40
40	545 00 80-84	SADA TESNENÍ		1	
41	530 01 58-97	SKRUTKA		1	
42	545 04 67-01	MODUL ZAPALOVARIA		1	
43	530 03 92-27	SHORTING LEAD		1	
44	530 01 64-56	SKRUTKA		1	
45	530 01 64-63	PODLOŽKA		1	
46	530 09 41-89	PODLOŽKA		1	
47	545 17 34-01	BEARING - THRUST		1	
48	530 01 64-20	WASHER - THRUST		1	
49	530 01 58-05	SKRUTKA	2010-72N AND LOWER, SEE SERVICE REFERENCE	1	
50	530 01 57-74	SKRUTKA	2010-72N AND LOWER, SEE SERVICE REFERENCE	1	
51	530 01 57-68	MATICA		1	
52	530 01 64-56	SKRUTKA		1	
53	545 20 52-01	SKRIŇA VENTILÁTORA	2010-72N AND LOWER, SEE SERVICE REFERENCE	1	
54	530 15 00-39	BUBÓN SPOJKY		1	
55	530 05 51-22	SPOJKA - ZOSTAVA		1	

Ref	Diel č.	Popis	Poznámka	Mno žstvo	SADA
56	530 05 78-52	KRÚŽOK		1	
57	530 03 92-42	ZOTRVAČNÍK		1	
58	545 19 56-01	CRANKCASE-CAST		1	
59	545 01 34-01	LOŽISKO		1	
60	545 19 52-02	ASSY-CRANKSHAFT		1	
61	530 01 51-62	POISTNÝ KRÚŽOK		1	
62	530 01 92-83	PIESTNY KRÚŽOK		1	
63	545 08 18-14	KIT		1	61, 62
64	545 00 80-83	KIT-PISTON/CYL.		1	63
65	545 00 80-84	SADA TESNENÍ		1	
66	530 01 58-97	SKRUTKA		1	
67	545 08 18-48	KIT - CARBURETOR		1	3, 4, 5
68	576 45 90-01	BASE		1	
69	530 05 78-46	COVER		1	
70	530 05 97-96	KNOB ASSY AIRBOX COVER		1	
71	545 00 80-84	SADA TESNENÍ		1	5, 7, 10, 11, 17, 40, 65
72	545 18 08-82	KIT-DECAL		1	