

136 LiHD50

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

A 136 LiHD50
CUTTING




Position	Article	Quantity	Notes	Kit
1	577 83 90-01	1		
2	578 37 22-01	1		
3	577 95 02-01	1		
4	581 27 96-01	1		

B 136 LiHD50
GEAR




Position	Article	Quantity	Notes	Kit
1	577 83 52-01	1		
2	577 83 45-01	1		
3	576 03 30-01	6		
4	581 27 42-01	1		
5	581 27 44-01	1		


C 136 LiHD50
HANDLE



Page C		136 LiHD50		Handle	
Position	Article	Quantity	Notes	Kit	
1	577 91 78-01	1			
2	579 21 19-01	2			



D 136 LiHD50
HOUSING





Position	Article	Quantity	Notes	Kit
1	578 09 38-01	1		
2	503 21 28-13	2		
3	578 10 31-01	1		

F 136 LiHD50
ACCESSORIES



Page F		136 LiHD50		Accessories	
Position	Article	Quantity	Notes	Kit	
1	578 08 19-01	1			
2	579 13 06-01	1			